



Guardian FABXR Bracket

> Assembly & Operation Guide

> Contents

Fiffing device into Bracket	4
PORTAGANTRY RAPIDE * 500	6
PORTAGANTRY (RAPIDE)* 1000	8
PORTAGANTRY* Small & Medium	10
PORTAGANTRY*	14
TDAVIT*	16
PORTADAVIT QUANTUM* Column	18
PORTADAVIT QUANTUM* Backstay Single Winch	20
PORTADAVIT GUANTUM* Backstay Double Winch	22
PORTADAVIT* 500	24
PORTX*DAVIT	26



Lightweight. Portable. Safe.

Please read the following instructions and guidance notes carefully. These have been designed to aid users in carrying out the correct assembly of the bracket for each of our compatible lifting systems. Systems compatible with this product are:

- > PORTAGANTRY RAPIDE
- > PORTAGANTRY*
- > TDAVIT
- > PORTADAVIT QUANTUM"
- > PORTADAVIT
- > PORTX*DAVIT

General Specification

- > Maximum rated capacity for fall protection 1 person
- > Ensure the rating of the Winch is always checked before use
- > For use with REID lifting products only

Standards

- > EN795:2012 Type B
- > EN1496:2017

For further information please refer to the technical data sheet for this product.

For operations guide and technical specifications for the device, please refer to the manufacturer's dedicated guide.

The following instructions detail the assembly of the Guardian FABXR device into the bracket on trap plate attachments.



Guardian FABXR Bracket

Prepare the bracket to receieve the device by removing the bolt from bottom connector and loosen off the top connector.



> Present the device to the bracket.



> Secure the Device by reinserting the bottom bolt to the connector. Tighten the top connector into a secure position.



> The device is now secure and ready to use.


> PORTAGANTRY RAPIDE® 500

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001020] for the PORTAGANTRY [MIDE] 500kg.





> Bracket is supplied with bolts and pins as shown.



Remove the bottom bolt from the trap plate and loosen the top bolt - do not fully remove.



Present the bracket to the trap plate, slotting the keyhole slot onto the loosened bolt. Once locked on, tighten the bolt.



Insert and secure the tommy screw into the bottom hole.



> The bracket is now ready to receive the device.

> PORTAGANTRY RAPIDE® 1000

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001020] for the PORTAGANTRY [MADE] 1000kg.





> Bracket is supplied with bolts and pins as shown.



Remove the bottom bolt from the trap plate and loosen the top bolt - do not fully remove.



Present the bracket to the trap plate, slotting the keyhole slot onto the loosened bolt. Once locked on, tighten the bolt.



Insert and secure the tommy screw into the bottom hole.



> The bracket is now ready to receive the device.

> PORTAGANTRY Small & Medium

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001020] for the PORTAGANTRY Small and Medium frame sizes.






> Bracket is supplied with bolts and pins as shown.




) Disassemble the bracket, separating the back plate from the faceplate.




> Remove top bolt from trap plate.



Present the bracket to the trap plate, securing using the M16 bolt provided.



> Remove the bottom bolt from the trap plate.



Carefully align the backplate and secure into the bottom hole on the trap plate using the M16 bolt provided.

> PORTAGANTRY® Small & Medium



> Reassemble the bracket using all bolts.



> The bracket is now ready to receive the device.


Guardian® Checkmate Bracket

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001000] for the PORTAGANTRY.






> Bracket is supplied with pins as shown.



Adjust the width of the wings to 76.2mm to fit comfortably on the column.




> Present the bracket to the column as shown.



> Secure using the pins provided.




> The bracket is now ready to receive the device.





> Bracket is supplied with pins as shown.



Adjust the width of the wings to 76.2mm to fit comfortably on the column.



> Present the bracket to the column as shown.



> Secure using the pins provided.




> The bracket is now ready to receive the device.

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001000] for the PORTADAVIT 500.





> Bracket is supplied with pins as shown.



Adjust the width of the wings to 50.8mm to fit comfortably on the backstay.



> Present the bracket to the backstay as shown.



> Secure using the pins provided.




> The bracket is now ready to receive the device.

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001000] for the **PORTA**DAVIT column. **Warning:** For this configuration a sheave bracket column is required.






> Bracket is supplied with pins as shown.



> Adjust the width of the wings to 76.2mm to fit comfortably on the column.



> Present the bracket to the column and secure using the pins provided.



> Present the sheave bracket* to the upper-most holes of the column.



> Secure using the pins provided.




> The bracket is now ready to receive the device.

*RAW000095 - Sheave bracket PDQ Column Medium Sheave (4-7mm).


> PORTADAVIT QUANTUM® Backstay Single Winch

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001000] for the PORTADAVIT [GUARDINE] Backstay.





> Bracket is supplied with pins as shown.



Adjust the width of the wings to 63.5mm to fit comfortably on the backstay.



> Present the bracket to the backstay as shown.



> Secure using the pins provided.



> The bracket is now ready to receive the device.


> PORTADAVIT QUANTUM® Backstay Double Winch

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001010] for the PORTADAVITION BACKSTAY.





> Bracket is supplied with pins as shown.



Adjust the width of the wings to 63.5mm to fit comfortably on the backstay.



> Present the bracket to the backstay as shown.



> Secure using the pins provided.




> The bracket is now ready to receive the device.

The following instructions detail the assembly of the Guardian FABXR bracket [RAWB001000] for the PORTX DAVIT.






> Bracket is supplied with pins as shown.



Adjust the width of the wings to 76.2mm to fit comfortably on the column.



> Present the bracket to the column as shown.



> Secure using the pins provided.



> The bracket is now ready to receive the device.

Contact Us

Head Office, UK

Unit 1 Wyeview Newhouse Farm Industrial Estate Chepstow Monmouthshire NP16 6UD United Kingdom

- > +44 (0)1291 620 796
- > enquiries@reidlifting.com
- > www.reidlifting.com

All information herein is copyright protected by REID Lifting Ltd. All company and product names are Trade Mark and Trade Name protected and all REID Lifting Ltd. Product IPR is protected under Patents, Patents Pending and/or Design Rights.

Printed using environment friendly processes and materials.